



Pfleiderer Deutschland GmbH
Ingolstädter Str. 51
92318 Neumarkt
Germany

Burgdorf, 16.06.2020

Test order No. 2019-0820

Date of order: 19.06.2019
Responsible:
Pages: 2

Method:

JIS Z 2801 Quantitative analysis for determination of the
bacteriostatic activity; film 35x35mm; inoculum 120ul:

SANITIZED AG

A handwritten signature in blue ink, appearing to read "E. Kohrbach".

Erich Kohrbach
Head Microbiology

The findings are valid for the tested object(s) only. Filing record of report and documentation is 10 years.

Results

Description of sample

Sample number: **2019-0820-02** Received: 19.06.2019
Business: POLYMER Type: QC
Identification: DecoBoard_microPLUS
Main Component: Melamine resin
Minor Component: Particle board
Field of Application: Decorative surfaces for interior application

Sanitized Products: Sanitized® Silver

Test results of the SANITIZED-laboratory

Quantitative analysis for determination of the bacteriostatic activity:				
Method	Test point	Activity	Reduction in %	Evaluation
JIS Z 2801	Escherichia coli ATCC 8739	>5.60	>99.99	Good effect
JIS Z 2801	Staphylococcus aureus (MRSA) ATCC 33592	>4.10	>99.99	Good effect